

OPERATING INSTRUCTIONS FOR THE “DRESTER DYNAMIC TRIPLE”

1. FIRST CHECK

- * **Check that the green lamp is lit and that the oil temperature has dropped to 50°C.**
(This means that the Recycler is cold, ready to start and may be opened)
- * **Check the plastic bag in the Recycler.**
(This is a single-use disposable bag it must be replaced after each use. If the bag is full of solvent, check that the distillate container under the Recycler is empty and then go directly to step 4)

2. TRANSFERRING SOLVENT

- * **Start the pumps of the RDX Docking Unit.**
(Open the valve on the right side of the Recycler)
- * **Turn off the pumps when they start to pump air.**
(Turn off the valve after about 2–3 minutes)

3. SECOND CHECK

- * **Check that the level indicator of the distillate container is all the way down.**
(If not, start the pumps again and let them run for a few more minutes. If the level indicator still does not drop to its lowest level, then the feed hose is may be blocked or a pump faulty, in which case you should contact an authorised Drester retailer)
- * **Check that the plastic bag in the Recycler is full of solvent.**
(Roughly up to the level of the ring clamp holding the bag. If not, start the pumps again and let them run for a few more minutes. If the bag still is not full, then the feed hose may be blocked or a pump faulty, in which case you should contact an authorised Drester retailer)

4. CLOSE THE COVER AND START THE RECYCLER

- * **Note: Information about settings for time and temperature can be found in the manual for the Recycler, no. 11213, section 5.5.**